

# proStrip roof tapes

featuring  
**MIRCOSEALANT**  
TECHNOLOGY

PRP  
**proSeal**™  
Roofing systems

## Tips & Installation Instructions

### Application Instructions

1. Locate area needing repair or joining

2. Clean the surface Allow to dry completely.

Recommended cleaners: Lacquer thinner, acetone, white gas (PVC ONLY)

3. Remove release liner. Only remove enough liner for the area you are working on. Keep adhesive side clean and dry. Apply tape to surface.

4. Apply pressure to activate bonding process. Use a steel roofer's roller for best results. The firmer the pressure or rubbing applied, the faster the bond.

• DOES NOT STICK TO SILICONE

For cold weather application, keep tape at room temperature before applying. Certain roof conditions and surface types may require the use of a primer. DON'T NOT USE PRIMERS ON PVC MEMBRANES



### Liner Removal to expose MircoSealant!

1. Grab the outer edges with thumb & forefingers.

2. Push fingers together, bunching the tape in the middle

3. In a fast motion, snap the tape forward and backwards 7-10times

4. Push fingers together again, allowing liner to "POP" from the tape

5. Peel liner from the tape and apply to the prepared surface.

### LAP SEALING WITH proStrip



Measure proStrip



Remove Liner



Apply and Roll



Remove Liner



Roll in membrane



JOB COMPLETE!

\* MircoSealant™ is a registered trademark of Eternabond/Royal Adhesives