



Note: Refer to drawing M211-011 for corner completion

CURB FLASHINGS

1. Cut membrane flashings to length
2. Extend membrane up curb to termination height required
3. Adhesive may be used as an option to secure membrane to curb
4. Membrane base must extend a min of 3" beyond field termination
5. Flashing membrane must be overlap a min of 3"
6. All curbs greater than 2' must have a termination bar installed

| | | | |
|---|--|------------------------------------|--|
| Project Name | RPW Associates, Inc. PO Box 35 Milton Ontario L9T 2Y3 | | |
| Project Address | Project # | | |
| Drawingd Title CURB FLASHING DETAIL | DATE: Nov 1/10 | DRAWING NUMBER: M211-010 | |